

Charge. Sync. Secure.

Charging systems from Ergotron



Windows 8

Designed for

Surface



kindle fire



SAMSUNG
SOLUTIONS EXCHANGE

Carts • Wall Mounts • Desktop Cabinets • Accessories

ERGOTRON®

Zip40:
Charge, secure and transport up to 40 devices with display sizes ≤15.6"

ONE charging system fits all!

Chromebooks • Tablets • Laptops



Zip12:
Charge and secure up to 12 devices with display sizes ≤14"



Zip40 Charging Cart & Zip12 Charging Desktop Cabinet

The latest in device charging technology, Ergotron Zip Charging Systems offer ultimate versatility, flexibility and security. Charge, secure and protect a wide variety of devices – most tablet, Chromebook™, MacBook® and laptop devices.

The ability to mix and match devices ensures your charging system will meet your needs today and well into the future. Adjustable dividers let you customize capacity:

- ✓ Standard 1.1"-wide (28 mm) slots
- ✓ Adjust slots to 1.4" (35 mm) to accommodate thicker devices with large cases
- ✓ Mix and match devices; move and remove dividers

Because the entire systems are fully safety certified, Zip systems are a smart choice for education, healthcare and enterprise applications.



Zip40 Highlights

Up to 30% FASTER Charging Speed

- Features Ergotron's PowerShuttle® power management technology; the system efficiently charges up to 30% faster than a standard round-robin system. With just one power cord plugged into a standard wall outlet, it safely prevents overloading of electrical circuits by automatically determining the maximum number of devices that can be charged at one time.

More AGILITY

- Zip40 dual-wheel, 5" casters create a super smooth ride over a variety of flooring surfaces; cube-like, compact shape makes it easy to zip through tight spaces

More SECURITY

- Rugged steel construction and durable steel doors include a 3-point locking mechanism with separate key lock; add padlock for additional door security
- Optional security bracket locks cart to floor or wall

More FLEXIBILITY

- Includes external auxiliary outlet to power peripherals
- Removable, locking rear-access door to the adapter storage area allows for easy, one-time setup and clean cable management
- Custom country-specific outlet strips include plenty of space to fit oversized wall plug or brick-style AC adapters
- Ethernet management capability also available; carts are upgradeable
- Location included for installation of a Wireless Access Point (WAP not included)

Zip12 Charging Wall Cabinet

- This slim cabinet is perfect for charging and securing up to 12 tablets (including Surface, Android and iPad) and Chromebook devices with screens up to 12"
- Show & Stow™ technology makes loading and unloading simple
- Slim profile — only 6" (15,2 cm) deep
- Smooth, sliding metal door with 6-point locking bracket keeps devices safe and secure
- Entire cabinet is tested and certified to UL 60950



Zip40 Charging Cart/ Zip40 Charging & Management Cart

Zip12 Charging Desktop Cabinet

Compatible Devices	Tablets, Chromebook, Ultrabook, MacBook and laptop devices with ≤ 15.6" LCD size with dimensions up to maximum 17,1"W x 11,2" H (43,4 x 28,4 cm) including case and power cord plug. <i>(Verify device dimensions for compatibility)</i>	Tablets, Chromebook or laptop devices with up to ≤ 14" LCD size with dimensions up to maximum 15.3"W x 9.7" H (38,9 x 24,6 cm) including case and power cord plug. <i>(Verify device dimensions for compatibility)</i>
Charge Method	Custom country-specific outlet strips include plenty of space to fit oversized wall plug or brick-style AC adapters; use adapters that come with devices	
Screen Size	≤ 15.6"	≤ 14"
# of Devices	Up to 40 with 1.1"-wide (28 mm) slots; up to 30 with 1.4"-wide (35 mm) slots	Up to 12 with 1.1"-wide (28 mm) slots; up to 8 with 1.4"-wide (35 mm) slots
	Full UL 60950 and UL 1678 certification	Full UL 60950 certification
Security	3-point locking steel doors with key lock assembly	

PowerShuttle® Carts

Laptop Charging • Laptop Management

- Universal design** ✓ Accommodates up to 20 laptops
- ✓ Two country-specific power strips are provided to plug-in AC adapters of varying sizes and shapes
- PowerShuttle** ✓ Innovative PowerShuttle technology automatically optimizes total charge and safely prevents overloading electrical circuits by efficiently grouping the number of devices that are charged at once
- Safe & secure** ✓ Robust lock-and-key assembly keeps devices secure
- ✓ Rugged steel frame construction, steel front and rear doors, and molded fire-rated ABS exterior
- ✓ Entire cart is tested and certified to UL 60950 and UL 1678 standards



Tablet Management Wall Mount 10

Tablet Management – Charge. Sync. Secure.

2.4A charge: Made for iPad® certified (pre-installed cables)

2.1A charge: Apple® iOS • Samsung Galaxy • Amazon Kindle • Google Nexus

Charging systems designed specifically for Samsung® Galaxy Tab® Active

- Charge and sync up to 10, 16, 32 or 48 devices simultaneously
- Switch from charge to sync mode by connecting a Macintosh® or PC
- Ventilated, enclosed storage keeps tablets protected
- Steel framework with durable locking steel doors keeps tablets secure
- Tablet management carts feature a small footprint making them easy to maneuver through tight aisles and easy to store
- Accommodates most tablet cases
- Wall Mount 10 features Show and Stow™ technology; devices are presented to user when door is opened
- Individual Status Indicators (ISI) monitor charging progress of each tablet (optional)



Zip12 Charging Wall Cabinet	PowerShuttle® Laptop Charging Cart	PowerShuttle® Laptop Management Cart	Tablet Management Wall Mount 10	Tablet Management Desktop 16*	Tablet Management Cart 32* & 48	Tablet Management Station 16
Most tablets and Chromebooks up to maximum dimensions 11.9"W x 8.9"H x 1.0"D (30,2 x 23 x 2,5 cm) including case. (Verify slot size for compatibility)	Laptops with screen sizes ≤ 15.6"	Laptops with screen sizes ≤ 15.6"	30-Pin with pre-installed cables: iPad, iPad 2, iPad (3rd generation) Lightning with pre-installed cables: iPad Air 2, iPad Air, iPad (4th generation), iPad mini 3, iPad mini with Retina® Display, iPad mini	30-Pin: iPad, iPad 2, iPad (3rd generation) Lightning with pre-installed cables: iPad Air 2, iPad Air, iPad (4th generation), iPad mini 3, iPad mini with Retina® Display, iPad mini	30-Pin: iPad, iPad 2, iPad (3rd generation) Lightning with pre-installed cables: iPad Air 2, iPad Air, iPad (4th generation), iPad mini 3, iPad mini with Retina® Display, iPad mini	Devices with USB 1.2 charging standard (See ergotron.com to verify device compatibility)
AC	AC	AC	USB 2.4A Made for iPad® (cables pre-installed)	USB 2.4A Made for iPad® (Lightning cables pre-installed) USB 2.1A (cables not included)	USB 2.4A Made for iPad® (Lightning cables pre-installed) USB 2.1A (cables not included)	USB 2.1A (cables not included)
≤ 12"	≤ 15.6"	≤ 15.6"	≤ 10.1"	≤ 10.1"	≤ 10.1"	Variable
12	20	20	10	16	32 or 48	16
Full UL 60950 certification	Full UL 60950 and UL 1678 certification		Full UL 60950 certification	Full UL 60950 certification	Full UL 60950 and UL 1678 certification	Full UL 60950 certification
Steel doors with 6-point key lock assembly				Steel doors with 3-point key lock assembly		Not Secure

* Also available and designed specifically for Samsung® Galaxy Tab® Active
Learn more at charging.ergotron.com





Zip40 Charging Cart



Zip40 Charging & Management Cart



Zip12 Charging Desktop Cabinet



Zip12 Charging Wall Cabinet



PowerShuttle Laptop Management Cart



PowerShuttle Laptop Charging Cart

US/CA/MX	DM40-1009-1	DM40-1008-1	DM12-1012-1
EU	DM40-1009-2	DM40-1008-2	DM12-1012-2
UK/IE/HK/MY/SG	DM40-1009-3	DM40-1008-3	DM12-1012-3
AU/NZ	DM40-1009-4	DM40-1008-4	DM12-1012-4
CN	DM40-1009-5	DM40-1008-5	DM12-1012-5
JP	DM40-1009-6	DM40-1008-6	DM12-1012-6

US/CA/MX	DM12-1006-1	24-246-085	24-291-085
EU	DM12-1006-2	24-250-085	24-295-085
UK/IE/HK/MY/SG	DM12-1006-3	24-249-085	24-294-085
AU/NZ	DM12-1006-4	24-251-085	24-296-085
CN	DM12-1006-5	24-247-085	24-292-085
JP	DM12-1006-6	24-248-085	24-293-085



Pre-installed cables USB 2.4A charging



Tablet Management Wall Mount 10 30-Pin



Tablet Management Wall Mount 10 Lightning



Tablet Management Desktop 16 with ISI / Lightning



Tablet Management Cart 32 with ISI / Lightning



Tablet Management Cart 48 with ISI / Lightning

US/CA/MX	DM10-1006-1	DM10-1007-1	DM16-1004-1	DM32-1004-1	DM48-1004-1
EU	DM10-1006-2	DM10-1007-2	DM16-1004-2	DM32-1004-2	DM48-1004-2
UK/IE/HK/MY/SG	DM10-1006-3	DM10-1007-3	DM16-1004-3	DM32-1004-3	DM48-1004-3
AU/NZ	DM10-1006-4	DM10-1007-4	DM16-1004-4	DM32-1004-4	DM48-1004-4
CN	DM10-1006-5	DM10-1007-5	DM16-1004-5	DM32-1004-5	DM48-1004-5
JP	DM10-1006-6	DM10-1007-6	DM16-1004-6	DM32-1004-6	DM48-1004-6

Accessories for Tablet Management Desktop 16 & Cart 32 or 48



30-Pin Cable Kit* (16 pack) 97-766
Lightning Cable Kit* (16 pack) 97-800
Cart Security Bracket 97-735

Accessories for Tablet Management Station 16 & Wall Mount 10



* Certified cable kits made for iPad are a custom length to fit perfectly with our Charging Systems

30-Pin Cable Kit* (10 pack) 97-812
Lightning Cable Kit* (10 pack) 97-801



Tablet Management Desktop 16 (with ISI) 2.1A Charge



Tablet Management Desktop 16 (without ISI) 2.1A Charge



Tablet Management Desktop 16 for Samsung Galaxy Tab Active (with ISI)



Tablet Management Cart 32 (without ISI) 2.1A Charge



Tablet Management Cart 32 (with ISI) 2.1A Charge



Tablet Management Cart 32 for Samsung Galaxy Tab Active (with ISI)



Tablet Management Cart 48 (with ISI) 2.1A Charge



Tablet Management Station 16 2.1A Charge

US/CA/MX	24-327-085	24-372-085	DM16-1015-1	24-373-085	24-328-085	DM32-1016-1	24-329-085	DM16-1003-1
EU	24-339-085	24-378-085	DM16-1015-2	24-379-085	24-340-085	DM32-1016-2	24-341-085	DM16-1003-2
UK/IE/HK/MY/SG	24-333-085	UK/IE 24-375-085	DM16-1015-3	UK/IE 24-376-085	24-334-085	DM32-1016-3	24-335-085	DM16-1003-3
AU/NZ	24-345-085		DM16-1015-4		24-346-085	DM32-1016-4	24-347-085	DM16-1003-4
CN	24-351-085		DM16-1015-5		24-352-085	DM32-1016-5	24-353-085	DM16-1003-5
JP	24-357-085		DM16-1015-6		24-358-085	DM32-1016-6	24-359-085	DM16-1003-6
TH	24-409-085		DM16-1015-9		24-410-085	DM32-1016-9	24-411-085	
KO	24-400-085				24-401-085		24-402-085	
IN	DM16-1021-B							

Apple, Macintosh, iPad and Retina are trademarks of Apple Inc., registered in the US and other countries. iPad Air, iPad mini and Lightning are trademarks of Apple Inc. Amazon, Kindle, Kindle Fire, the Amazon Kindle logo and the Kindle Fire logo are trademarks of Amazon.com, Inc. or its affiliates. Windows is a registered trademark of Microsoft Corporation. © 2012 Google Inc. All rights reserved. Android and Chromebook are trademarks of Google Inc. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License.

© 2015 Ergotron, Inc. Literature made in the U.S.A. 07/28/2015
Content is subject to change without notification
Ergotron devices are not intended to cure, treat, mitigate or prevent any disease



A Nortek Company

Americas Sales and Corporate Headquarters

St. Paul, MN USA
(800) 888-8458
+1-651-681-7600
www.ergotron.com
sales@ergotron.com

EMEA Sales

Amersfoort, The Netherlands
+31 33 45 45 600
www.ergotron.com
info.eu@ergotron.com

APAC Sales

Tokyo, Japan
www.ergotron.com
apaccustomerservice@ergotron.com

Worldwide OEM Sales

www.ergotron.com
info.oem@ergotron.com