

HP Tablet Charging Module



Say goodbye to stacks of tablets and a sea of power cords. Quickly and easily charge, update, store, and secure up to 10 tablet PCs inside the HP Tablet Charging Module so they're ready when you need them.

Charge and update your HP ElitePad or any AC-powered tablet device up to 11.6 diagonal inches.

Get easy one-time hardware setup by connecting each tablet's AC adapter to the module's interior power strip and plugging the module into an AC outlet. A blue LED HP logo lights up to confirm the module is powered.

Push updates to your HP ElitePad tablets with an optional HP ElitePad Power/Ethernet Adapter or HP Tablet Module LAN Upgrade Kit, which allow simultaneous charging and connection to your Ethernet cables. The integrated cable tray keeps things tidy.

The doors fold back for easy loading and unloading of tablets. Removable, adjustable dividers support storage of thicker tablet devices and devices with jackets and cases.

A front door keyed lock keeps the tablets securely housed while charging, and an external lock secures the module to a counter or desk. The thermally-efficient design stays cool to the touch and a vented back panel and two fans help circulate air.

Keep tablets ready to deploy for field and mobile personnel. The module is perfect for doctors and nurses to charge and update their devices between rounds, and ideal for classroom settings to secure, update, and charge student tablets overnight.

Get peace of mind from the worldwide limited three-year warranty.

HP Tablet Charging Module

Part number	J6X15AA
Weight (w/o computer equipment)	14.1 kg (31 lbs)
Dimensions (W x D x H) Estimated standalone height - Includes the rubber feet and rear flare	460 x 551.5 x 316.6 mm (18.1 x 21.7 x 12.46 inches)
Compatibility	<p>AC-powered tablet devices up to 11.6 diagonal inches. Can also be used on the following HP ElitePad with the following jackets and cases:</p> <ul style="list-style-type: none"> • 10 HP ElitePad Security Jackets • 10 HP ElitePad Rugged Case (removing the hands strap) • 10 HP ElitePad Expansion Jacket and HP ElitePad Expansion Jacket with Battery

HP Tablet Module LAN Upgrade Kit

Push Ethernet updates and charge up to 10 HP ElitePad tablets (sold separately) simultaneously in your HP Tablet Charging Module with the HP Tablet Module LAN Upgrade Kit.

Use the included HP ElitePad Power/Ethernet Adapters to connect your tablet's power cable and an Ethernet cable (sold separately) to each HP ElitePad.

Hold the adapters in place, keep the interior of the module tidy, and help ensure accurate, uninterrupted data transfers with the included dongle holders.

Get peace of mind from the worldwide limited one-year warranty.

Part number	K7H15AA
Kit includes	<p>10 - HP ElitePad Power/ RJ45 Adapter P/N F9D31AA 10 - Plastic Adapter Holder 10 - Plastic 90 Degree Elbow Documentation</p>

