

Full 2.4A charging capability

Charges iPad Air in approximately 4 hours –
33% faster than 2.1A solutions

ERGOTRON®**Highlights****Top-rated Sync & Charge**

- Built-in syncing capability; simultaneously sync up to 10 devices by connecting your laptop via the cabinet's USB port

Safe & Secure

- Tested and certified to UL 60950-1 standards, FCC requirements and all applicable country-specific regulations
- Six-point lock assembly provides strong theft deterrence; includes security screws to attach product to the wall
- Fan and ventilation system maintains safe operating temperature
- Ergotron not only uses UL-certified components, but goes a step further to have UL certify the entire system to guarantee safe use within the classroom, healthcare, or enterprise setting

Slim & Open Design

- Fits most anywhere: very low profile – only 4" (10 cm) deep, even with access doors
- Accommodates most iPad cases – including the popular Otterbox Defender™ and Griffin Survivor™

Easy Set-up & Operation

- Quick, simple installation includes mounting template
- Patent-pending Show & Stow™ technology extends iPad devices to the user when the door is opened for easy storage and removal
- Easy to clean, sleek and smart design hides device and cord clutter
- Clear ISI (Individual Status Indicator) LEDs provide power and charging status of each individual device at a glance

Tablet Management Wall Mount 10 — for iPad**Ready. Set. Charge.****Choose pre-installed 30-pin or pre-installed Lightning cable option**

Sleek, low-profile design accommodates all generations of Apple iPad Air, iPad and iPad mini devices. Durable steel doors with robust six-point lock and key assembly provide strong theft deterrence. Full 2.4A charging and syncing capability. Tested and certified to UL 60950-1 standards.

- Compact Size: 23.2" W x 31.8" H x 4.0" D (59 x 80,9 x 10,2 cm)
- Easy installation:
 1. Mount two brackets on the wall using installation template
 2. Hang wall mount unit
 3. Secure to wall with security screws
 4. Install power cord cover
 5. Plug iPad devices into unit
 6. Plug Tablet Management Wall Mount into the wall outlet
- Includes external USB 2.0B port to connect laptop for syncing (USB cable not included)
- Cooling/ventilation: one 12V DC continuous operation fan
- Power system: input: 100-240V~, 2.0A, 50/60 Hz
- Temperature range:
 - Operating 0° to 30°C (32° to 86°F)
 - Storage -40°C to 60°C (-40° to 140°F)
- Relative humidity (maximum):
 - Operating 10–90% (non-condensing)
 - Storage 5–95% (non-condensing)
- Altitude (maximum): 2000 m (6,562 feet)
- Environmentally clean: RoHS, REACH, WEEE and EU (94/62/EC) packaging compliant
- Entire system certified to UL 60950-1 and UL 2442. Complies with FCC Part 15 Class A requirements



TABLET CASES – The following cases have been tested and confirmed to work with the Tablet Management Wall Mount 10 product. This is not a comprehensive list. If your cover fits within the maximum dimensions of 10.2"H x 7.9"W x 0.9"D (25.9 x 20.1 x 2.3 cm) with the cable plugged in, it should also fit.

iPad Air: Apple iPad Smart Case, Griffin Survivor, Gumdrop Drop Tech, Otterbox Defender Series (without separate top cover), Speck FitFolio, STM studio, STM dux, UZBL Airwave

iPad 2/iPad (3rd generation)/iPad (4th generation): Apple iPad Smart Case, Belkin Protective Case with Stand, Belkin Tri-Fold Folio, Belkin Snap Shield, Brenthaven Bionic, Cascrowd Trifold Case, Cascrowd Omni, Griffin Survivor, Griffin Intellicase, Gumdrop Drop Tech, Hard Candy Street Skin, Logiix Roadster II, Otterbox Defender Series (without separate top cover), Otterbox Reflex Series, Speck FitFolio, STM Skinny 3, STM Grip, Targus SafePort Rugged and Rugged Max Pro, Targus Slim Case, Targus Versavu, Trident Aegis, Trident Kraken AMS.

For iPad		Tablet Management Wall Mount 10	
Charging	2.4A with ISI	2.4A with ISI	
Pre-installed Cables	30-Pin	Lightning	
Part # (silver/black)	US/CA/MX DM10-1006-1 EU DM10-1006-2 UK/IE/SING/HK/MY DM10-1006-3 AU/NZ DM10-1006-4 CN DM10-1006-5 JP DM10-1006-6	US/CA/MX DM10-1007-1 EU DM10-1007-2 UK/IE/SING/HK/MY DM10-1007-3 AU/NZ DM10-1007-4 CN DM10-1007-5 JP DM10-1007-6	
Compatible Devices (most cases fit)	iPad, iPad2, iPad (3rd generation)	Pad Air 2, iPad Air, iPad (4th generation), iPad mini 3, iPad mini with Retina® Display, iPad mini	
UL Certification	Yes		
Maximum Dimensions Individual Tablet (including cover)	≤ 10.2" H x 7.9" W x 0.9" D (25,9 x 20,1 x 2,3 cm)		
Weight Capacity	24 lbs (11 kg) 2.4 lbs (1,1 kg) per device		
Shipping Dimensions	36.5" x 26.4" x 7.0" (92,6 x 67 x 17,7 cm)		
Shipping Weight	39.5 lb (17,9 kg)		
Warranty	Five (5) years workmanship/mechanical components, two (2) years on power module, one (1) year on electrical components		



Apple, iPad, and Retina are trademarks of Apple Inc., registered in the US and other countries. iPad Air, iPad mini, and Lightning are trademarks of Apple Inc.

© 2014 Ergotron, Inc. rev. 12/08/2014/EA Literature made in US
Content is subject to change without notification

Americas Sales and Corporate Headquarters	EMEA Sales	APAC Sales	Worldwide OEM Sales
St. Paul, MN USA (800) 888-8458 +1-651-681-7600 www.ergotron.com sales@ergotron.com	Amersfoort, The Netherlands +31 33 45 45 600 www.ergotron.com info.eu@ergotron.com	Tokyo, Japan www.ergotron.com apaccustomerservice@ergotron.com	www.ergotron.com info.oem@ergotron.com

ERGOTRON®