

HP Hot Desk Stand



Streamline your setup

Enhance productivity and provide a comfortable workspace for your mobile and flexible workforce with immediate connectivity to a display and peripherals with the HP Hot Desk Stand.

Assemble in a snap

Easily install the stand on a desk or table. Secure the clamp with two thumbscrews, slide the monitor arm on, and add one display up to 32" diagonal with four additional thumbscrews. Use the cable management features to keep your work area tidy.

Ready, set, dock

Add an HP USB Dock to create a universal touchdown station, then connect your everyday accessories and input devices for a workspace that's ready as soon as you connect your notebook.

Get in the zone

Adjust the height and viewing angle of your mounted display to your specific comfort settings.

Rest easy

Get the reassurance of a one-year limited warranty.

Specifications



HP Hot Desk Stand

| | |
|---------------------------------------|---|
| Part number | W3Z73AA |
| Weight | Packaged 14 lbs (6.4 kg) Unpackaged 12 lbs (5.4 kg) |
| Maximum Display Size Supported | 32 inches |
| Load | 7 - 25 lb (3.2 - 11.4 kg) |
| Form Factor | Desktop |
| Lift Range | 22 - 33 cm |
| Tilt Range | 70 degrees backward 5 degrees forward |
| VESA Mount Standard | 100 mm 75 mm |
| Display Rotation | 360 degrees |
| Desk Clamp | 0.4 - 2.6 in (10 - 66 mm) |
| Service and support | One-year limited warranty. Additional support is available via online support forums. |
| Kit contents | HP Hot Desk Stand and documentation |

Sign up for updates
hp.com/go/getupdated



Share with colleagues



Rate this document

