

Overview

HP Multi-Tablet Charging Module

Model

H4W98AA

Compatibility

The HP Multi-Tablet Charging Module is compatible with AC-powered tablet devices up to 11.6 diagonal inches.

Service and Support

The HP Multi-Tablet Charging Module is supported by a three-year limited warranty. Additional support is available by phone as well as online support forums.

Technical Specifications

Module dimensions (W x D x H)	18.1 x 21.7 x 12.5 in (460 x 551.5 x 316.6 mm)
Module weight (w/o equipment)	31 lb (14.1 kg)
Stacking weight capacity (on frame)	68.3 lb (31 kg)
Notebook bay dimensions (W x D x H)	1.2 x 13.8 x 10.16 in (30.5 x 350.5 x 258 mm) NOTE: Tablet dividers are removable, enabling creation of variable width slots.
Shipping dimensions (W x D x H)	21.5 x 25.4 x 15.4 in (545 x 645 x 390 mm)
Shipping weight	37.5 lb (17 kg)
Power	External: HP 65 Watt AC Adapter with 5.9 ft (1.8 m) cable; included Internal: 10 country-specific outlets for charging tablets factory pre-installed. NOTE: AC adapters for powering each tablet are customer-supplied and installed. NOTE: Module AC input is filtered and protected by two 15- or 10-amp (according to region) circuit breakers and then distributed to each tablet's AC adapter and the 65-watt 19-volt AC distribution power supply.
Cooling	Two 12-volt DC fans; Perforated front doors, rear ventilation panel, and tablet dividers provide additional ventilation.
Security doors	Two aluminum locking doors open from the front center and slide in to the side pockets. Interior latch keeps unlocked doors closed. Top and rear access covers are removable to allow access to internal outlets, AC Adapters, AC Distribution box and fans. Covers may be secured to allow authorized access. Top cover includes a feature to help deter liquids from making contact with internal contents.
Service compartment	Includes the AC distribution box, internal outlets, 2 fans, 1 HP 65W AC power adapter for powering the AC distribution box. Access to the service compartment may be restricted via a security screw lock out feature.
Cable Wrap Tray	Cable wrap tray allows the user to neatly store excess power adapter cable length and feed the tablet power connector through the pass-through holes to the tablet in the slots below.
Security loop	Theft deterrent cable loop to secure the module to a fixed location via a cable or tether.
Lower Recess	Undercut recesses on opposite ends of the module assist in picking up the module.
LED Status Indicators	One blue power-on LED on the front of the module
Product Storage and Transportation Temperature	-29° to +60° C (-20° to 140° F)
Relative Humidity (storage)	5% to 95% (non-condensing)
Operating Temperature	0° to 30° C (32° to 86° F)
Operating Relative Humidity	10% to 90% (non-condensing)
Altitude	0 to 6562 ft (0 to 2,000 m)
Environmental	RoHS, REACH, WEEE, UL 60950-1, CAN/CSA C22.2 No. 60950, ICES-003 Issue 4, Class A, FCC Part 15 Class A, IEC 60950-1, GOST-R, KCC, EN55022, EN55024
Kit contents	HP Multi-Tablet Charging Module, power cord, security screw/wrench, and 1 set of keys.

© Copyright 2013 Hewlett-Packard Development Company, L.P.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.