



HP Integrated Work Center Stand USDT/Thin Clients

The perfect fit for your workspace

Introducing a premier combination of computing performance and flexibility for small workspaces and public areas.

HP Integrated Work Center Stand shown with an HP Compaq LA2306x 23-inch WLED Backlit LCD Monitor and an HP Compaq 8200 Elite Business PC, keyboard, and mouse (both products sold separately).

Create a complete system

The HP Integrated Work Center Stand is designed to help maximize the use of limited desk space without compromising performance or productivity by accommodating an 8000 Series HP Ultra-slim Desktop PC or an HP Thin Client¹ and most HP 17 to 24-inch² diagonal LCD monitors with VESA standard mounting brackets.

Simply mount the USDT or Thin Client on to the back plate with four simple screws, and then attach the monitor to the front of the stand with the included HP Quick Release. Next, neatly route the cords into the cable management clip and insert the power supply into the secure spring-loaded drawer to enable the monitor and PC to be combined into a complete system, creating a convenient "all-in-one" form factor.

Enjoy a space-saving solution

Do you work in an environment that has space constraints? Do you require maximum space efficiency? If so, the HP Integrated Work Center Stand for a USDT or Thin Client is the perfect fit for your business.

Enjoy this premier combination of computing performance and monitor flexibility in areas such as office cubicles, retail POS, display kiosks, tradeshow booths, lobbies, financial centers, healthcare facilities, laboratories, temporary work sites, education labs, or group workspaces that are frequently rearranged.

Adjust and adapt your environment

This stand is sure to impress with features that include:

- An adjustable stand with tilt, height and swivel lets you change positions throughout the day, helping you stay comfortable and productive
- Slim neck design reduces excess material and weight, helping to reduce environmental impact
- Spring loaded retention drawer securely holds power supplies of many sizes
- VESA mounting holes enable high or low positioning of the USDT or Thin Client
- Cable management clips help keep cables neatly dressed and concealed behind the stand
- New cable pass-through design simplifies cable routing and enables a clutter free workspace



HP Integrated Work Center Stand – USDT/Thin Clients

Part number	LH526AA
Tilt Range	-3 to +20 degrees vertical tilt
Swivel Range	-180° to + 180°
Height adjustable	Yes, range: 13.5 cm (5.3 in)
Dimensions (h x w x d)	Packaged: 36,19 x 37,35 x 25,05 cm (14.25 x 14.7 x 9.93 in) Unpacked: 32,0 x 49,0 x 43,8 cm (12.6 x 19.3 x 17.2 in)
Weight	Packaged: 4,9 kg (10.8 lbs) Unpackaged: 3,1 kg (6.8 lbs)
Supported weight capacity²	The Integrated Work Center Stand has been designed to support 17 to 24-inch diagonal HP LCD monitors from 3.4 kg to 4.8 kg (7.5 lbs to 10.5 lbs). See list below for supported models.
Limited warranty	The Integrated Work Center Stand carries a one-year limited warranty. Technical support is available seven days a week, 24 hours a day, by phone, as well as online support forums. Certain restrictions and exclusions apply.
Compatibility	The Integrated Work Center Stand USDT / Thin Client is designed to exclusively accommodate the HP Compaq 6005 Pro, or Elite dc8000, dc8100, or dc8000f Ultra-slim Desktop PC or HP Thin Client ¹ and the HP LCD monitors shown below (each sold separately)

Supported Monitors

Monitor	Monitor Part Number(s)	Monitor	Monitor Part Number(s)
ESSENTIAL SERIES		ADVANTAGE SERIES	
LE1711	EM886AA	LA1751g	EM889AA (available in select regions)
LE1851w	NK033AA	LA1905wg	NM360AA, NM360A2 (TAA compliant/US only)
LE1851wl	XL867AA (available in select regions)	LA1951g	EM890AA, EM890A2 (TAA compliant/US only)
LE19f	VV081AA	LA1951gl	XL875AA (available in select regions)
LE1901w	NK570AA	LA2006x	XN374AA
LE1901wl	XL877AA (available in select regions)	LA22f	VU893AA
LE1901wm	NP446A	LA2205wg	NM274AA, NM274A2 (TAA compliant/US only)
LE1911	EM887AA	LA2206x	XN376AA
LE2001w	NK128AA	LA2306x	XN375AA
LE2001wl	XL866AA (available in select regions)	LA2405wg	NL773AA (Product must be used in conjunction with a USDT or Thin Client to be supported.)
LE2001wm	VN692AA (available in select regions)		
LE2201w	NK571AA		
TOUCH SERIES		PERFORMANCE SERIES	
L2105tm	EM891AA	ZR22w	VM626A4

1. With the exception of HP gt7720 and HP gt7225 Thin Clients.

2. HP monitors weighing 3.4 kg to 4.8 kg (7.5 lbs to 10.5 lbs).

© 2011 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein. To learn more, visit www.hp.com

MARCH 2011

